



- LIFTING INSTRUCTION**
- Before lifting the unit, check the weight on the label to select appropriate lift equipment.
  - Make sure that the external panels is firmly fixed in place, before lifting the unit.
  - Lifting the unit, use only lifting points provided.
  - The lifting belts must be of equal length.
  - Use a spread-bar to avoid damage to the unit.
  - The movement must be performed with caution, avoid abrupt movements.

SVM	Spring type vibration mounting (Opt.)
RVM	Rubber type vibration mounting (Opt.)

	Order	Serial number	Czech republic, Hradec Králové, Piletická 486	
			Scale 1:17	Title
	Designer		Size A1	Chiller AAC6-330CR
	Approved		Weight 3545	Number of drawing AAC6-330CR.00.00
Date				
Material			Series: AAC	Version: 6-330CR